



Protection and Care for Royal Floor Planks, Herringbone, Chevron and Tiles/Panels

Maintenance instructions

The natural growth and structure of the wood is giving Krügers wooden floors their special touch. The finish protects the floor from external influences. The room climate is very important for maintaining the value and texture of Krügers flooring. The ideal room climate is achieved at 18 - 22° C and a relative humidity of 50 - 60%. It is important that the air humidity remains as constant as possible. This can be achieved with an average room size, e.g. with water containers on the central heating radiators or electric air humidifiers.

Treatment (Initial treatment)

Your Krügers floor needs an initial treatment after installation. Remove the installation dirt from the floor by using a sweeper or vacuum cleaner (do not wipe wet). Then apply a thin layer of maintenance oil to the floor and polish the surface. We recommend the products of the manufacturer Osmo. Attention: If you have chosen a floor with the surfaces ORIGINAL, NATURAL or REAL, use the special product „ Osmo Wisch-Fix “ to keep the raw wood look (invisible look). In any case, please follow the instructions of the product manufacturer.

Maintenance Treatment

The floor should be cleaned regularly of dust and dirt (sweeping, vacuuming, etc.). The floor should only be wiped slightly wet. Standing water has to be avoided in general. Afterwards, wipe the floor dry with a non-fibrous piece of cloth. We recommend adding a suitable care product for oiled floors (e.g. Osmo Wood Floor Soap) to the cleaning water at regular intervals, depending on the wear and conditions. Please follow the instructions of the product manufacturer.

Preventive Protection

Surfaces are subject to natural wear and tear. To maintain the value of your wooden floor, we recommend fitting gliders under chair- and table-legs and also using foot runners in the entrance area. For wheels under seats or wheelchairs, we recommend the use of clear plastic mats.